

## Installation Tools

SPINNER supplies trimming tools for fast, correct stripping of foam dielectric cables with corrugated outer connectors. These tools can be used in the factory or in the field to reduce the assembly time by more than 60%.

SPINNER supplies flaring tools for large air dielectric cables and 52-120 rigid line to ensure optimal RF contact. They can be equipped with inserts for different cable types.

### Trimming Tools

Cable Type	Part Number
SF 1/2"-50	<b>BN 541334</b> for CAF® <b>BN 541354</b> for MultiFit®
LF 1/2"-50	<b>BN 541317</b> for CAF® <b>BN 541387</b> for MultiFit®
LF 7/8"-50	<b>BN 541318</b> for CAF® <b>BN 541301</b> for MultiFit®
LF 1 1/4"-50 LF 1 5/8"-50	<b>BN 541346</b> - Heavy duty type with crank
HCA 58-50	<b>BN 541341</b>
HCA 78-50	<b>BN 541342</b>



### Flaring Tools

Cable Type	Flaring Tool	Insert
HCA 118-50	<b>BN 511411</b>	<b>BN 511447</b>
HCA 158-50	<b>BN 511411</b>	<b>BN 511457</b>
HCA 295-50	<b>BN 511411</b>	<b>BN 511481</b>
HCA 300-50	<b>BN 511411</b>	<b>BN 511469</b>
HCA 400-50 (HCA 318-50)	<b>BN 511411</b>	No insert required
HCA 400-50 (HCA 318-50)	<b>BN 511400</b>	<b>BN 511442</b>
HCA 495-50	<b>BN 511400</b>	<b>BN 511443</b>
HCA 550-50	<b>BN 511400</b>	<b>BN 511444</b>
HCA 618-50	<b>BN 511400</b>	No insert required
Rigid line 52-120 BT	<b>BN 511400</b>	<b>BN 511445</b>

